

Primo Oval Grill Unpacking Instructions

Instructions for Primo Oval XL 400, Oval LG 300, and Oval JR 200

Two Adults are Needed to Assemble the Grill.


Tools Needed: 7/16" and 1/2" Wrenches.

IMPORTANT: DO NOT LIFT GRILL BY THE HINGE WHEN INSERTING INTO A GRILL TABLE

1 Select a smooth level area for unpacking, assembly, and insertion into a grill table. Ensure plenty of working space such as a garage or driveway.




2 Open the top of the box, open the center flaps to reveal the top vent. Remove the top vent from the grill, then the top cardboard cover.



3 Remove the cardboard inner protector around the grill and lay it flat. Use it to place the grill's internal components on it in Step 5.



4 Remove the outer cardboard. *For an Oval XL 400 grill, attach the handle with a 1/2" wrench. Do not over tighten. Open the grill carefully.



5 Have an adult stand behind the grill and hold it securely to prevent tipping. Remove the internal components.



6 Place the grill table or cart nearby and lock the casters. The top front bar on metal carts can be removed for easier installation.



7 Two adults are required to lift the grill into a grill table or final location. One adult in the front and one behind. Open draft door and use the opening as a lifting point (Fig 1). From the back, firmly grasp the top of the base and lift the grill (Fig 2). **DO NOT LIFT THE GRILL BY THE HINGE.**

8 BEFORE AND AFTER FIRST USE. Use a box wrench to ensure that both bands are tight. Do not over tighten. Check tightness periodically.





Figure 1



Figure 2

Primo Ceramic Grills
3289 Montreal Industrial Way
Tucker, GA 30084
Phone: 770-492-3920

Register Your Grill at PrimoGrill.com